



# Electromotive 2/2 way angle seat valve

- Fail-safe position by energy storage
- Rapid flow shut off
- Weather and impact resistant design
- · Designed according to hygienic demands
- Many diagnostic functions



The innovative Bürkert On/Off process valve Type 3320 is the solution when it comes to shut-off tasks under demanding operating conditions. The electromotive actuator with ball screw moves the swivel plate at a particulary high rate of 6 mm/s to its end position. Thereby it reacts almost instantaneously to process signals. If necessary, the safety position can be approached by an optional energy storage in case of power failure. The actuator and shut-off valve are adapted perfectly to each other with closed design and robust surface. This ensures the hygienic requirements of a fast and residuefree cleaning. Harsh environments are no problem for the Type 3320 because of the protection class IP65 / IP67 and its high impact and vibration resistance. Unrivalled cycle life and sealing integrity is guaranteed by the proven self adjusting spindle packing with exchangeable V-seals. The fieldbus suitable for Type 3320 provides many helpful functions for process monitoring, valve diagnostics and predictive maintenance and thus offers the decisive advantage of a modern process automation.

Technical data				
Port size	DN15 to DN50			
Nominal pressure (max.)	PN25 (valve body)			
Port connections Thread Welded Clamp	G, RC, NPT (EN ISO 228-1, ISO 7/1 / DIN EN 10226-2, ASME B 1.20.1) EN ISO 1127 / ISO 4200, DIN 11850 R2, ASME BPE, BS 4825-1, SMS 3008 DIN 32676 A, DIN 32676 B, ASME BPE, BS 4825			
Medium	neutral gases, water, alcohol, oils, fuel, hydraulic mediums, salt solution, alkali solutions, organic solvents, steam			
Viscosity	max. 600 mm <sup>2</sup> /s			
Medium temperature	-10 to +185 °C (seat seal PEEK) -10 to +130 °C (seat seal PTFE)			
Ambient temperature	-25 to +65 °C * (without SAFEPOS energy-pack) -25 to +55 °C * (with SAFEPOS energy-pack) * Note: Derating see temperature chart			
Safety position at power failure	with SAFEPOS energy-pack: opened, closed or free programmable without SAFEPOS energy-pack: blocked in last position			
Power supply	24 V DC ±10% (max. residual ripple 10%)			
Closure time	<2.34.3 sec. (depending on stroke)			
Travel speed	6 mm/s			
Duty cycle	100 %			
Protection class	IP65 / IP67			
Binary control	05 V (log. 0) 1030 V (log. 1)			
Fieldbus communication	büS (Bürkert-System-Bus) (Standard) CANopen, EtherNet/IP, Modbus/TCP, PROFINET (optional)			
Vibration, sinusoidal	5 g according to IEC 60068-2-6 Test Fc			
Shock, mechanical	50 g according to IEC 60068-2-27 Test Ea			
Approval and Conformity	EGV 1935/2004 (standard) FDA (optional) ATEX / IECEx (optional) cULus Cert. No. 238179 (optional)			
Ignition protection	II 3G Ex ec IIC T4 Gc II 3D Ex tc IIIC T135 °C Dc			

www.burkert.com

1/14




## Structure and function

The electromotive linear actuator consists of a brushless direct current motor, gears and a threaded spindle. The valve spindle, which is connected to the threaded spindle, transfers the force to the swivel plate. The electronic control system is actuated either via a standard signal (digital) or via a fieldbus (digital). Optionally there is the energy pack (SAFEPOS energy-pack) for the device. If the supply voltage fails, the energy pack supplies the actuator with the required energy to move the valves into the required position which can be adjusted via a menu.


The valve position can be manually changed in 2 ways. Either over an electrical manual control or over mechanical manual control, if no supply voltage applied. The device can be set and operated either via 2 capacitive buttons and 4 DIP switches. There is also the option of setting the device via the büs Service interfache and by using the PC software "Bürkert-Communicator".


The intelligent process valve Type 3320 offers the operator options for process monitoring, valve diagnostics and predictive maintenance. Internal measurements for the operating state are evaluated and, if issued as a warning or error message. This signal, for example, undue environmental and process conditions, functional deviations of components or the state of the energy accumulator. Internal measurements for operating state are evaluated and, possible a warning or error message is issued. This signal indicates, for example, bad environmental and process conditions, functional deviations of the energy accumulator.





## **Controls and indicators**







## Control elements

The basic functions are operated by 4 DIP switches and 2 pushbottons. These are located under the dummy cover which can be removed manual by turning. Through the büS service access, the device can also be configured in detail with the Bürkert communicator software. For this, the optional USB-büS interface kit is required.


#### Manual and electrical operation

The manual override for mechanical operation of the valve is located under the dummy cover.

Electrical manual override for the procedure is carried out y by two buttons below the dummy cover.

#### 360°- LED Illuminated ring

To display the device status, the valve end position and the operating condition, a visible 360° LED illuminated ring is mounted around the dummy cover. The LED ring lights up, flashes or flashes in one or different colors. Depending on customer requirements 4 different LED modes can be selected (Namur mode, valve mode without warnings, valve mode with warnings, LED off)




#### Mechanical position indicator

The mechanical position indicator also indicates when the supply voltage of the current valve position fails





## Controls and indicators, continued



#### SIM card as data storage (option)

With the SIM card optional device-specific values and user settings can be saved and quickly transferred to another device.




büS service interface Connection for CAN adapter or USB-büS interface set

#### büS service interface

The büS service interface connects the device to the communicator software on a PC, laptop or smartphone. From there, a configuration of the device or failure diagnosis can be performed.



## Design and materials view




Note: The angle-seat shut-off valve Type 3320 could be delivered with miscellaneous port connection (thread, welded and clamp), there are not represented in the picture, but are made with same material as the valve body.




## **Technical data**

#### **Temperature chart**

The maximum allowable ambient temperature and temperature of the medium influence each other. The maximum allowable temperature curves of different device variants can be seen in the temperature chart. The curves were determined for maximum operating conditions (max. operating pressure and motor power). For deviating operating conditions an individual verification can be performed. Please contact your Bürkert office for more information.



#### Selection chart for seat seal




#### Flow direction below seat

Port size (pipe)		Operating pressure / valve seat seal				
[DN]	[inch]	PTFE [bar]	PEEK [bar]	[m³/h]		
15	1/2	16	16	5		
20	3⁄4	16	16	11		
25	1	16	16	18		
32	1¼	16	10	31		
40	11/2	10	8	42		
50	2	6	5	62		

## **Electrical control**

Electrical data	
Protection class	3 acc. to DIN EN 61140
Electrical connections	Cable gland, 2 x M20 or 2 circular plug-in connector M12, 5 pin and 8 pin
Operating voltage	24 V DC ±10% max. residual ripple 10%
Operating current [A] <sup>1.)</sup>	max. 3 A including actuator at max. load and charging current of the optional SAFEPOS energy-pack (charging current approx. 1 A)
Lifelong energy storage SAFEPOS energy-pack	up to 10 years (depending on operating conditions)
Average power electronics without drive [W] <sup>1,)</sup>	min. 2 W, max. 4 W
Control	
Output digital	current limit 100 mA
Input digital	05 V = log "0", 1030 V = log "1" inverted input reversed accordingly
Communication interface (büS)	Connection to PC via USB büS interface set (connection terminals, circular connectors or büS service interface)
Communication Software (büS)	Bürkert communicator Type 8920

1.) All values refer to a supply voltage of 24 V at 25  $^\circ\text{C}$ 



#### Electrical control and interface

The position of the actuator is regulated according to the digital input. The setting is made either by an external standard signal (digital) or via a fieldbus (digital).

burkert

#### **Digital Control**

For digital control 2 variants are available for the inputs and outputs and the connection interface

#### Input and output:

• 1 digital input, 2 digital output

#### Interface:

• Cable gland with connection terminal

• M12 circular connectors (optional)

## Fieldbus: EtherNet/IP, PROFINET, Modbus TCP (option)


The Fieldbus Gateway for EtherNet / IP, PROFINET and Modbus TCP is integrated into a special module. It has 2 fieldbus connections with 4 pin M12 circular connectors. Under the gateway housing cover are the interfaces for the fieldbus connection and status LEDs. If there is a need to be include it in a network then the configuration of the Ethernet can be performed via the web server.








## Dimensions [mm] - valve Type 3320 and valve system





## Dimensions [mm] - body valve Type 3320




## G, RC, NPT (EN ISO 228-1, ISO 7/1 /DIN EN 10226-2, ASME B 1.20.1)

Port size (pipe)				G		NPT		RC	
	СМ	LM	SW	D	E	D	E	D	E
[DN]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
15	24	65	27	G ½	14	NPT ½	13.7	RC 1/2	13.2
20	27	75	34	G ¾	16	NPT 34	14.0	RC ¾	14.5
25	29.5	90	41	G 1	18	NPT 1	16.8	RC 1	16.8
32	36	110	50	G 1¼	16	NPT 11/4	17.3	RC 1¼	19.1
40	35	120	55	G 1½	18	NPT 11/2	17.3	RC 11/2	19.1
50	45	150	70	G 2	24	NPT 2	17.6	RC 2	23.4




## Dimensions [mm] - body valve Type 3320



Port size (pipe)				DIN 11850 R2 DIN 11866 Series A DIN EN 10357 Series A			ASME BPE DIN 11866 Series C					
	CS	LS	ØDS	WS	CS	LS	ØDS	WS	CS	LS	ØDS	WS
[DN]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]	[mm]
15	34	100	21.3	1.6	34	100	19	1.5	34	100	12.7	1.65
20	39	115	26.9	2.0	39	115	23	1.5	39	115	19.05	1.65
25	43	130	33.7	2.0	43	130	29	1.5	43	130	25.4	1.65
32	40	145	42.4	2.0	40	145	35	1.5	-	-	-	-
40	49	160	48.3	2.0	49	160	41	1.5	49	160	38.1	1.65
50	50	175	60.3	2.6	50	175	53	1.5	50	175	50.8	1.65



## Dimensions [mm] - body valve Type 3320





## Ordering chart for accessories

Accessories	Article no.			
Connection cable:				
Connection cable with M12 socket, 4 pin, (length 5 m) for operating voltage	918038 🚎			
Connection cable with M12 socket, 8 pin, (length 2 m) for input and output signals	919061 👾			
USB-büS interface set:				
büS stick set 1 (including power supply unit, bus-stick, terminating resistor, Y-distributor, 0.7 m cable with M12 connector)	772426 👾			
büS stick set 2 (including bus-stick, terminating resistor, Y-distributor, 0.7 m cable with M12 connector)	772551 👾			
büS adapter for büS interface set (M12 on büS service interface Micro-USB)	773254 👾			
büS cable extensions from M12 plug to M12 socket:				
Connecting cable, length 1 m	772404 👾			
Connecting cable, length 3 m	772405 👾			
Connecting cable, length 5 m	772406 👾			
Connecting cable, length 10 m	772407 👾			
Miscellaneous				
Bürkert Communicator	Infos at www.burkert.com			
SIM card	291773 🛒			
Holding device for line connection DN15 to DN20	693770 🛒			
Holding device for line connection DN25 to DN50	693771 📜			

## burkert

Note You can fill out the fields directly in the PDF file before printing out the form.

## Valve system - request for quotation

## Please fill out and send to your nearest Bürkert office\* with your inquiry or order

-		
Company:		Contact person:
Customer no.:		Department:
Address:		Tel./Fax.:
Postcode/town:		E-Mail:
= mandatory fields to fill out	Quantity:	Required delivery date:
Operating data		
Pipe line	DN	PN
Pipe Material		
Process medium		
Type of medium	Liquid	Steam Gas
Valves features		
valves teatures		
Valve seat seal	PTFE	PEEK
Nominal pressure	PN	
Seat size (orifice)	DN	
Type of connection	Threaded	Welded
Specify connection		
Control function	with energy sto (delivey status)	
	with energy sto (delivey status	





## Valve system - request for quotation, continued

Control unit features	
Communication	
Binary	Digital (Fieldbus)
1 binary IN	EtherNet/IP
2 binary OUT	PROFINET
	Modbus TCP
Electrical connection	
Cable gland (without Fieldbus)	Multipol
SIM card	Approval and Conformity (optional)
with	ATEX II Cat 3G/D / IECEx
without	CULus Cert. No. 238179
Article no. (if known):	
Notes	

To find your nearest Bürkert office, click on the orange box ightarrow

www.burkert.com

In case of special application conditions, please consult for advice.

Subject to alteration. © Christian Bürkert GmbH & Co. KG

1904/8\_EU-en\_00895317

14/14